

Technical Bulletin Number 3 Installation Instructions for Columns Adjoining Walls

If you wish to use Protect-it MAXI to protect a wall, we recommend the following attachment method.

1. Assemble the Protect-it MAXI's in a wall format as per the images below.
2. Protect-it MAXI wall will take the shape of the surface that you wish to protect.
3. We recommend fastening a minimum of two Protect-it MAXI's in every five MAXI's to the wall using screws and plugs.
4. Drill a hole the same diameter as the screw through the front and back of the Protect-it MAXI just above the centre. As per the image below.
5. Enlarge the front hole so that is bigger than the screw head, allowing the screw to pass through to the back of the Protect-it MAXI.
6. Then use these holes to fasten it to the wall using a screw and wall plug. We recommend a minimum screw size of 5mm (3/16 ")

